

PDX COCK COMPRESSOR VIBRATING STROKER

User manual



CONTROL

- 1) Press the control button to turn the masturbator on.
- 2) Repeated pressing changes the vibration modes and holding the button for 3 seconds turns the masturbator off.
- 3) The pressure control is similar. Pressing the control button activates the function.
- 4) Pressing repeatedly changes the mode of the air bag function and holding the button for 3 seconds turns the function off and the pressure in the masturbator is reduced.
- 5) The LED indicator glows red when vibrating, for the air bags function it glows green, both colours flash when both functions are activated.
- 6) If you are charging the masturbator, the light is red, you will know a full charge by the green light.

MAINTENANCE

Always remove the insert from the masturbator after each use and rinse with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The stroker is **water resistant**, so maintenance is very easy.

The stroker can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The stroker is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a stroker and USB cable for charging.