

YOUTOYS GLAMOUR SET

(VIBRATING EGG AND VIBRATOR)



User manual

EGG CONTROL

- 1) Insert 2 AA batteries into the remote control.
- 2) Start the egg by pressing the ON button, which is also used to increase the vibration.
- 3) To turn off and reduce vibration, press the OFF button.

VIBRATOR CONTROL

- 1) The bottom of the vibrator serves as a cover for the batteries.
- 2) Unscrew the cover and insert 2 AA batteries and screw the cover back on.
- 3) Start the vibrator by turning the wheel at the bottom of the cover.
- 4) Turn the same wheel to control the intensity of the vibration.

MAINTENANCE

After each use, rinse the tools with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The tools are **not waterproof or water resistant!**

LUBRICATION

Due to the material of the egg, you can use **lubricants of any base**.

DRIVE AND CHARGING

The vibrator is powered by two AA batteries.

The egg is powered by two AA batteries.

We recommend the use of alkaline or rechargeable batteries for greater endurance.

The vibrating ring is powered by an internal disposable battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.