

Please read the specification carefully before using this product.


# Instruction manual

## Vibrator

### English

#### Specifications

Material: Silicone, ABS  
Charging: Lithium battery  
Use time: 90 minutes  
Frequency: 10 frequency + remote control  
Size: 66MM(L)+46MM(W)  
Remote control: 23A 12V Dry battery (Not included)  
Waterproof: Remote control (not waterproof),  
Vibrator(IPX 7)  
Packaging includes: Vibrator, Remote control, Cable,  
Instruction manual



- ① NO/OFF
- ② Magnetic charging
- ③ High-intensity vibration button
- ④ Remote control NO/OFF
- ⑤ Frequency button

#### Vibration mode

- ① Low speed vibration
- ② Medium speed vibration
- ③ High speed vibration
- ④ Small wave vibration
- ⑤ Big wave vibration
- ⑥ Single pulse vibration
- ⑦ Double pulse vibration
- ⑧ Rhythmic vibration
- ⑨ Dynamic vibration
- ⑩ Provocative vibration

#### Steps for usage

##### Vibrator mode

- 1: Long press the ON/OFF button for 1.5 seconds, feel the vibration, the indicator light is on, go to standby
- 2: Short press the ON/OFF button, switching frequency, a total of 10 frequencies, the light is off
- 3: Long press the ON/OFF button for 1.5 seconds, shut down, the motor stops vibrating

##### Remote control mode

- 1: Long press the remote control ON/OFF button for 1.5 seconds, boot, the indicator light is on, remote control mode is on, long press the remote control ON/OFF button for 1.5 seconds, shut down, indicator off, when the vibrator is in standby state, the indicator light is on
- 2: Short press the High-intensity vibration button, turn on high-intensity vibration, short press the High-intensity vibration button, the vibration restores the original strength

#### Attention

- ◆ 1: Disinfect the product before each use, it is recommended to use warm water and antibacterial soap (It is not recommended to use alcohol for long-term cleaning because it will corrode the vibrator and accelerate aging) and dry with a towel or a soft cloth
- 2: Before using the vibrator, if the head is not smooth enough or has burrs, please do not use
- 3: Do not use massage oil, hand cream, detergent, gasoline, or acetone as a lubricant

- 4: Clean the vibrator as soon as possible after use to avoid breeding bacteria
- 5: If used to stimulate the anus, use it with care to avoid falling into the body and causing damage to your body. It is best to use lubricant together before use, the effect is better
- 6: This product is a personal product. For your health, please do not mix it with others
- 7: This product uses hypoallergenic silicone. If it causes discomfort or allergies, stop using it immediately
- 8: Please keep it in a cool place, and do not touch other chemicals, if the part is eaten by a child or a pet, please go to the hospital immediately

#### Customer service:

7 Days 24 Hours Online Customer Service, Free Returns / Exchanges