

Operating Instructions

Suction, Tongue, and Vibration can be used simultaneously or independently.

• **Tongue Power On/Off:** Press the tongue power button to initiate tongue motion. Press the power button to cycle through 7 tongue motion patterns. Press and hold to turn off.

• **Vibration Power On/Off:** Press the vibration power button to initiate vibration. Press the power button to cycle through 10 patterns of vibration. Press and hold to turn off.

• **Suction Power On/Off:** Locate the convenient release button that can be used to pulse or stop suction. Press and hold the suction power button to initiate suction. Press and hold to turn off suction.

Care Instructions Cleanup is a snap after the fun with antibacterial cleaner and warm water.

 **Rechargeable Battery**

90 Minute Charge Time = 60 Run Time

**Powerful G-Spot
Vibration!**

G-Spot Vibration Power Button

10 Vibration Patterns

Quick Release Button

Enjoy pulsing suction or immediate release.

Suction Power Button

3 Suction Patterns

Tongue Power Button

7 Motion/Vibration Patterns

- Length with Attachment: 10" (25.4 cm)
- Length without Attachment: 9.5" (24.1 cm)
- Width: 1.5" (3.8 cm)

Caution: This vibrator is not intended for therapeutic purposes and is recommended for external use only. Prolonged and frequent use is not advised or recommended as these items are sold for novelty purposes only. This vibrator is intended for adult use only.

